

IN Series Tester

Installation & Usage Tips

Install the top first..... Then push the bottom in, making sure the 60pin connector is lined up....



Remove tester by pulling the bottom out of the 60pin connector.

LED Note: Each product will be unique in what lights are shown. Reference the text next to each LED or just look for a change of state when turning the inside lever, or opening the door, etc...

Lock toggle switch:

A momentary push UP will pulse the outside lever to the unlocked state. There is no need to hold the switch.
A momentary push DOWN will pulse the outside lever to the locked state. There is no need to hold the switch.
Using this tool, the lock can be left in either state.

“No Backplate Needed Here”

These connections allow for testing of lock bodies and DPS switches without the need for a backplate. Just align the wiring harness properly and then test normally.